

**FIMER**



# Solar Inverter PVS-20/30/33-TL

## Quick Installation Guide

In addition to what is explained in this quick installation guide, the safety and installation information provided in the product manual must be read and followed. The technical documentation for the product is available at the website.

The device must be used in the manner described in the manual. If this is not the case the safety devices guaranteed by the inverter might be ineffective.

**APPLY HERE  
THE WIRELESS  
IDENTIFICATION LABEL**

# 1. Inverter models and components


This Quick Installation Guide is related to the following inverter models:

Inverter model	Input channels	DC switch	DC SPD	DC connection	AC SPD	AC connection
PVS-20-TL-SXD PVS-30-TL-SX PVS-33-TL-SX	4	Yes	Type 2	8 string input	Type 2	Pluggable Terminal Block
PVS-30-TL-SY PVS-33-TL-SY	4	Yes	Type 1+2	8 string input	Type 2	Pluggable Terminal Block
PVS-33-TL-SI	4	Yes	Type 2	8 string input	Type 2 (IT system)	Pluggable Terminal Block

**NOTE** – The inverter model should be chosen by a specialized technician who has a good knowledge of the installation conditions, the devices that will be installed externally, and whether it will eventually be integrated into an existing system.

## 1.1 Main inverter components

Inverter external view		
01 Inverter	10 USB connector for accessories board	19 Padlock hole
02 Heatsink	11 Ethernet 1/2 connectors	20 Digital input cable gland (M20)
03 Synoptic	12 Digital input connector	21 Ethernet 1/2 cable gland (M25)
04 Protective earth (PE) external connection point	13 Quick fit input connectors	22 EXT cable gland (M25)
05 Mounting bracket	14 Wi-Fi antenna connector	23 AC cable gland (M40)
06 Fan tray	15 Smart button	24 Protective earth (PE) internal connection point
07 DC disconnect switch	16 Anti-condensation valve	25 Handles (optional)
08 Signals connection box	17 AC output connector	26 Rear anchor point
09 AC connection box	18 Side bracket screws (M5)	




**READ THE MANUAL** – See the manual for details on the connection of the communication and control signals.

## 2. Labels and Symbols


The labels on the inverter show the conformity marking, main technical data and identification of the equipment and manufacturer.

**NOTE** – The below labels are intended as an example only.




**Regulatory Label**

- Certification marks
- Inverter model
- Main technical data



**Identification Label**

- Inverter Model
- Inverter Part Number
- Inverter Serial Number consisting of:
  - YY = Year of manufacture
  - WW = Week of manufacture
  - SSSSS = sequential number
- Week/Year of manufacture
- Manufacturer















**Wireless Identification Label**

- WLAN embedded board Serial Number
- WLAN embedded board Part Number
- Inverter Serial Number:
  - Wireless access point SSID created by the inverter: FIMER-SSSSSSSSSS
  - "Host Name": http://FIMER-SSSSSSSSSS.local
  - It is required to register the inverter in Aurora Vision.
- MAC address
- Product Key:
  - To be used as wireless access point password, or to be used to access to the Web UI as username and password in case of lost credentials, and to commission inverter using ABB Installer for Solar Inverters.

**ATTENTION** – The labels placed on the equipment absolutely **MUST NOT** be removed, damaged, dirtied, hidden, etc.

In the manual and/or in some cases on the equipment, the danger or caution areas are indicated with signs, labels, symbols, icons.

Symbol	Description
	Always refer to instruction manual
	General warning - Important safety information
	Dangerous voltage
	Hot surfaces
	Protection rating of equipment
	Temperature range
	Without insulation transformer
	Direct and alternating current, respectively
	Positive and negative pole of the input voltage (DC)
	Obligation to use protective clothing and/or personal protective equipment
	Point of connection of the protective ground
	Risk of electric shock. The discharge time (quantified in the figure by the number XX) of the stored energy after de-energizing of the Inverter from both DC side and AC side.

## 3. Lifting and transporting

### Transportation and relocation

The transportation of the device, in particular via land transportation, must be made with adequate means and ways to protect the parts from violent impacts, humidity, vibrations, etc.

**ATTENTION** – If the package is stored correctly, it can withstand a maximum load of 3 stacked units.

### Lifting

The means used for lifting must be suitable to bear the weight of the equipment.

### Weight of the equipment components

Model	Weight
All models	50 Kg / 110 lbs


### Unpacking and inspection

The packaging components must be removed and disposed of according to the applicable regulations of the country where the device is installed. Upon opening the packaging, check the integrity of the equipment and verify that all the components are present.

If you notice defects or deterioration, stop the operations and call the carrier, as well as inform FIMER Service immediately.

Please keep the packaging in the event it has to be returned; the use of inadequate packaging will void the warranty.

Always store the Quick Installation Guide, all the supplied accessories in a safe place




## 4. Installation planning

### General recommendation on installation position

- Refer to Technical data table to check the required environmental conditions (protection rating, temperature, humidity, altitude, etc.).
- The installation location shall be easily accessible.
- Installation of the unit in a location exposed to direct sunlight is NOT acceptable. (Add awning in case of direct sunlight installation).
- Final installation of the device must not compromise access to any disconnection devices that may be located externally.
- Do not install in small closed rooms where air cannot circulate freely.
- Always ensure that the flow of air around the inverter is not blocked so as to prevent overheating.
- Do not install in locations where flammable substances or gases may be present (minimum distance 3 m).
- Do not install on wooden walls or other flammable supports.
- Install on a wall or strong structure suitable to bear the weight.
- Do not install in rooms where people live or where the prolonged presence of people or animals is expected, because of the high noise that the inverter produces during operation. The level of the sound emission is heavily influenced by where the appliance is installed (for example: the type of surface around the inverter, the general properties of the room, etc.) and the quality of the electricity supply.

### Tilting admittance


The unit can be installed with an inclination between 0° (horizontal) and 90° (vertical) as indicated in the figures below.



### Distances

- Maintenance operations from FIMER service could entail removing the front cover. Always observe the required installation safety distances in order to allow routine check and maintenance operations.


- Provide a sufficient working space in front of the inverter that allows to removing the front cover (FIMER service only) and to allows wiring connections.
- Install at a height which takes into consideration the weight of the unit and in a position which is suitable for servicing, unless suitable means will be provided to carry out these mentioned operations.
- If possible, install at eye-level so to allow to easily check the synoptic (03).
- Do not install any object (e.g. AC or DC cables) that could be damaged by overheating from outgoing hot air flow coming from top side ( $\Delta T = +15^{\circ}\text{C}$  compared to ambient temperature). In case of this kind of installation needs, please evaluate the installation of a proper air deflector. Always respect the minimum distances required.
- Respect the minimum distances from surrounding objects that could prevent the inverter installation and restrict or block the air flow:  
 A = 70cm (27")  
 B = 50cm (20")  
 C = 20cm (8") (60cm/24" for fan replacement)  
 D = 20cm (8")  
 E = 15cm (6")  
 F = 15cm (6")




**⚠ ATTENTION** – Please check the manual for some particular scenarios that may vary the minimum clearance distances:

#### Installation of multiple units

- In case of installation of multiple units in the same place, position the inverter side by side paying attention to keep the minimum clearance distance **G** of 30cm/12" (measured from the outer edge of units).



If the space available does not allow this arrangement, position the inverters in a staggered arrangement so that heat dissipation is not affected by other inverters below. Respect the following minimum clearance distances **H** of 100cm/39" and **I** of 30cm/12".













**⚠ ATTENTION** – Please check the product manual for "Wireless signal environmental checks", "Installations at high altitudes" and "Installations with a high level of humidity":

**NOTE** – The final installation of the inverter must not compromise the access to any disconnection devices located outside.

**NOTE** – Refer to the warranty conditions to evaluate the possible exclusions related to an improper installation.

## 5. Supplied Component list

Component	Q.ty
	Vertical or horizontal mounting bracket 1
	AC connector counterpart 1
	Reducing seals for reducing the clamping ranges of the AC cable gland (M40) (23). 1
	Eyelet cable lug for Protective earth (PE) internal connection point (24) 1
	M6 screw + M6 serrated lock washers to clamp the earth cable on the Protective earth (PE) internal connection point (24) 1 + 2
	M6 screw + M6 serrated lock washers to clamp the earth cable on the Protective Earth (PE) external connection point (04) 1 + 2
	DRM0/Remote ON-OFF connector counterpart 1
	Wireless antenna 1
	M5 screws (with washers) for mechanically securing the inverter to the bracket 2
	Technical documentation 1

## 6. Assembly instructions


#### Bracket installation

The mounting bracket can be used to install the inverter on a vertical or horizontal support.

- Position the mounting bracket (05) perfectly level on the support and use it as drilling template.

**NOTE** – It is the installer's responsibility to choose an appropriate number and distribution of attachment points. The choice must be based on the type of support (wall, frame or other support), the type of anchors to be used, and their ability to support 4 times the inverter's weight (4x50Kg/110lbs=200Kg/440lbs for all models). Depending on the type of anchor chosen, drill the required holes (4 minimum) to mount the bracket. Put at least 2 screws in the upper side and at least 2 in the lower side.

- Attach the bracket (05) to the support.





#### Assembly the Inverter to the bracket

**⚠ ATTENTION** – It is recommended to use the handles (that have to


be ordered separately) to handle and safety install the inverter.

**⚠ ATTENTION** – Risk of injury due to the heavy weight of the equipment. Always consider the center of gravity of the enclosures while lifting.

- Lift the inverter up to the bracket (05) (using the handles (25) or M8 eyebolts) and insert the heads of the two rear anchor points (26) (placed on the rear part of the inverter) into the two slots  on the bracket (05). Check that the rear anchor points (26) has been correctly inserted in the slots before releasing the inverter.



- Remove the handles (25) or eyebolts and tighten the supplied two side bracket screws (18) (Tightening torques 3.5 Nm) to avoid the tilting of the bottom part of the inverter.
- A padlock can be installed to lock the inverter to the bracket so that it cannot be disassembled by outsiders.



- Remove the protective cover from the connector of the wireless antenna located on the bottom side of the inverter. Install the wireless antenna by screwing it into the specific connector (14).

- Remove the 2 protective adhesive films on the bottom side of the inverter.

**⚠ ATTENTION** – The protective adhesive films, positioned on the connection area, DO NOT guarantee the IP degree of the inverter. Do not perform incomplete installations. Install the Connection Box AC and signals also if the electrical connection is not made immediately.

## 7. AC grid output connection

### 7.1 Characteristics and sizing of the protective grounding cable

The earth connection can be made through the Protective Earth (PE) internal connection point (04), Protective Earth (PE) external connection point (24) or both (this is required by regulations in force in certain countries of installation). In compliance with standard IEC 62109 it is necessary to install a earthing cable in one of the protective earth terminal with a minimum section as indicated in the table below:

Cross-sectional area of the phase conductors (S) (mm <sup>2</sup> )	Minimum cross-sectional area of the protective earthing conductor (mm <sup>2</sup> )
$S \leq 16$	S
$16 < S \leq 35$	16

**⚠ WARNING** – The minimum cross section of the protective earthing conductor must be:  
 - Copper wire = 10mm<sup>2</sup>  
 - Aluminum wire = 16mm<sup>2</sup>


### 7.2 Characteristics and sizing of the line cable

The AC cables must be connected to the AC output connector (17) using the specific terminal block supplied.

#### Conductor cable

AC cable gland	22 - 32 mm - size M40
Cable diameter range	20...26 mm - size M40 with reducing seals (supplied) installed

- max 35mm<sup>2</sup> - accepted by the AC screw terminal block for R,S,T and neutral.



Conductor cross section

- max 25mm<sup>2</sup> - accepted by the cable lug supplied for PE connection on the Protective Earth (PE) internal connection point (04).



**NOTE** – If is necessary to install a PE cable cross section greater than 25mm<sup>2</sup> can be used the Protective Earth (PE) external connection point (24)

Conductor material	copper or aluminum
--------------------	--------------------

### 7.3 Protection switch under load (AC switch) and sizing of the line cable

To protect the AC connection line of the inverter, we recommend the installation of a protection device against overcurrent and earth leakages with the following features:


Load protection breaker	PVS-20-TL	PVS-30-TL	PVS-33-TL
Type	Automatic circuit breaker with thermal-magnetic protection		
Voltage/current rating	400Vac min63A (*)	400Vac min80A (*)	400Vac min80A (*)
Magnetic protection	Magnetic curve B/C		
Number of poles	3W (3 phases without neutral wire) or 4W (3 phases with neutral wire).		
Differential protection type	A/AC		
Differential sensitivity	300 mA		

(\*): please consider thermal and other derating when selecting the current rating of the protection equipment for your application.

### 7.4 AC output cables connection

**⚠ ATTENTION** – Before carrying out any operation, check that any external AC switch downstream to the inverter (grid side) are in OFF position applying LOTO procedure on it.


The connection of the AC cable must be made on the AC output connector (17) located on the bottom side of the inverter by passing through the AC cable gland (23) installed on the AC connection box (09).



- Unscrew the AC cable gland (23) installed on the AC connection box (09).

- Pass the AC cable (diameter 22...32 mm) through the AC cable gland (23).

If the AC cable have a diameter between 20...26 mm should be installed the supplied reducing seal.



Based on the AC connection type could be possible 3 scenarios:



- Connection to the AC connector with PE on the Protective earth (PE) internal connection point (24)
- Connection to the AC connector with PE on the Protective earth (PE) external connection point (04)
- Connection to the AC connector with 2xPE; one on the Protective earth (PE) internal connection point (24) and the second one on the Protective earth (PE) external connection point (04)

### 7.4.1 Connection on the AC connector

- Strip the cable.

- Install R, S, T and N (if provided) on the AC connector respecting the connections as indicated on the connector (Tightening torques 2.5 Nm if the wire  $\leq 25 \text{ mm}^2$ ; 4.5 Nm if the wire  $> 25 \text{ mm}^2$ ).

**⚠ ATTENTION** – In case of a wrong phase sequence the inverter will not connect to the grid and it will provide an error state.




- Insert the AC connector and lock it in place by screwing the two lateral retaining screws.

### 7.4.2 Connection on the Protective earth (PE) internal connection point (24)

- Install the earth wire on the Protective earth (PE) internal connection point (24) following the installation sequence (Tightening torques 4 Nm):


- Serrated washer
- Earth cable
- Serrated washer
- M6 screw



### 7.4.3 Connection on the Protective earth (PE) internal connection point (04)

- Install the earth wire on the Protective earth (PE) internal connection point (04) following the installation sequence (Tightening torques 4 Nm):

- Serrated washer
- Earth cable
- Serrated washer
- M6 screw



### 7.4.4 Final operation

- Install the AC connection box (09) by tightening the 4 fixing screws
- Tighten the AC cable gland (23) (Tightening torques 8 Nm).

**⚠ ATTENTION** – Make sure the cable glands are properly sealed to ensure to keep IP protection degree.

## 8. Input connection (DC)

For the string connections it is necessary to use the DC input quick fit connectors (13), located on the bottom side of the inverter.

The input connectors are divided into 4 groups (one group for each input channel). For each channel 2 pairs of quick fit connectors are available. Respect the Maximum DC input power for each MPPT as follow:

MPPT	
IN1	22A / 10kW
IN2	26A / 12kW
IN3	22A / 10kW
IN4	26A / 12kW

16

### 8.1 Operations preliminary to the connection of the PV generator

- Checking the correct polarity of the strings
- Checking of leakage to ground of the photovoltaic generator
- Checking of strings voltage
- Installation of quick-fit connectors


### 8.2 Connection of inputs

**⚠ WARNING** – When the photovoltaic panels are exposed to sunlight they provide continuous DC voltage to the inverter. To avoid risks of electrical shock, all wiring operations must be carried out with the DC disconnect switches (internal (07) and external to the inverter) and external AC disconnect switches OFF.

- Connect all the strings required by the system by pushing the quick fit connectors in the right position.

**⚠ ATTENTION** – Using mating parts that are not compliant with the quick fit connector models on the inverter could cause serious damage to the unit and lead to invalidation of the warranty.

**⚠ ATTENTION** – Refer to document "String inverters - Product manual appendix" available on the website to find out the manufacturer and model of quick fit connector used on the inverter.




**⚠ ATTENTION** – Check that protective caps are installed to unused connectors. This is necessary for the inverter seal and to avoid any damage to the unused connectors which may be used at a later time.


**⚠ ATTENTION** – The quick fit connectors must be properly installed. After the installation make sure the connectors are correctly locked through the clips.

# 9. Instruments


The synoptic (03) allows to view inverter status conditions to be analyzed in greater depth by consulting the manual.




**POWER**  
Solid when the inverter is working correctly. Flashes when checking the grid or if there is insufficient sunlight.



**WLAN**  
Quality of the wireless communication signal.



**ALARM**  
The inverter has detected an anomaly. The anomaly is shown on the "EVENTS" section of the internal webserver.



**GFI**  
Ground fault on the DC side of the PV generator. The error is shown on the "EVENTS" section of the internal webserver.

**NOTE** – The icons, in various combinations, can indicate multiple conditions other than the original single condition; see the various descriptions on the product manual.

# 10. Commissioning

The inverter can be commissioned in a simple and intuitive way through the Installer for solar inverters APP for mobile devices.

- NOTE** – The same configurations can be done via internal web User Interface (see product manual).

  - Supply the inverter with DC input voltage from the photovoltaic generator and via AC grid voltage.
- ATTENTION** – The inverter configuration can be also performed with only one supply source (DC or AC).


**ATTENTION** – With DC supply, make sure that the irradiation is stable and adequate for the inverter commissioning procedure to be completed.

  - Open the "Installer for solar inverters" APP.
  - Login or Sign-In to Aurora vision account.
  - Tap on "Commissioning wizard". A QR code scanner will be opened.

Scan the QR code on the Communication identification label and connect to inverter network.

**NOTE** – The name of the Wi-Fi network created by the inverter will be: FIMER-ZZZZZZZZZZ (10 digit Inverter SN).


**NOTE** – After this step wait 10 seconds to allow the Wi-Fi connection. Once connected, the commissioning wizard will start.



## 10.1 COMMISSIONING WIZARD

### 10.1.1 Network configuration.


- Choose the connection type (ethernet or wireless) and set the related parameters.



- Once network parameters were settled, tap on "Next".


### 10.1.2 Date and Time.

- Set the Date, Time and Time zone (The inverter will propose these fields if connected to internet).
- Once date and time were settled, tap on "Next".




### 10.1.3 Inverter configuration.

**Country standard**  
Set the grid standard of the country in which the inverter is installed. From the moment that the grid standard is set, you have 24 hours to make any changes to the value. Some Country standards have different grid voltage that should be setted during this step.



- Confirm the settings by clicking "Save". The configuration wizard is complete and the inverter will reboot.



- If the outcome of the preliminary checks on the grid parallel is positive, the inverter connects to the grid and starts to export power to the grid. The "Power" LED remains fixed on while the "Alarm" and "GFI" LEDs are off.

**NOTE** – To address any problems that may occur during the initial stages of operation of the system and to ensure the inverter remains fully functional, you are advised to check for any firmware updates in the download area of the website [www.fimer.com](http://www.fimer.com) or at <https://registration.solar.fimer.com> (instructions for registering on the website and updating the firmware are given in the product manual).

# 11. Features and Technical Data

	PVS-20-TL	PVS-30-TL	PVS-33-TL
<b>Input side</b>			
Absolute maximum DC input voltage (Vmax,abs)		1100 V	
Start-up DC input voltage (Vstart)		250...500V (default 430V)	
Operating DC input voltage range (Vdcmín...Vdcmax)		200...1000 V	
Rated DC input voltage (Vdcr)		620V	
Rated DC input power (Pdcr)	20500 W	30600 W	33700 W
Number of independent MPPT		4	
Recommended maximum PV array power (PPV, max)	34000 Wp	44000 Wp	48000 Wp
Maximum DC input power for each MPPT (MPPT,max)		MPPT 1 (IN1) and MPPT 3 (IN3) = 10000W@22A MPPT 2 (IN2) and MPPT 4 (IN4) = 12000W@26A	
MPPT DC voltage range (VMPPtmin ... VMPPtmax) at Pacr		460-850V	



	PVS-20-TL	PVS-30-TL	PVS-33-TL
Maximum DC input current (Idcmax) for each MPPT	MPPT 1 (IN1) and MPPT 3 (IN3) = 22A ; MPPT 2 (IN2) and MPPT 4 (IN4) = 26A		
Maximum input short circuit current for each MPPT	40 A <sup>(7)</sup>		
Maximum return current (AC side vs DC side)	Negligible in normal operating conditions <sup>(8)</sup>		
Number of DC inputs pairs for each MPPT	2		
DC connection type	PV quick fit connector <sup>(9)</sup>		
Type of photovoltaic panels that can be connected at input according to IEC 61730	Class A		
<b>Input protection</b>			
Reverse polarity protection	Yes, from current limited source		
Input over voltage protection for each MPPT	SPD Type 2 / Type 1+2 (optional)		
Photovoltaic array isolation control	Yes, according to IEC 62109-2 or according local regulation		
Residual current monitoring Unit (leakage current protection)	Yes, according to IEC 62109-2		
DC switch rating for each MPPT (version with DC switch)	50A@600Vdc, 40A@800Vdc, 30A@1000Vdc		
String Fuse	Fuseless		
Input current monitoring	String level		
<b>Output side</b>			
AC Grid connection type	Three phase (3W+PE or 4W+PE)		
Earthing system	TN-S, TN-C, TN-CS, TT	TN-S, TN-C, TN-CS, TT	TN-S, TN-C, TN-CS, TT, IT <sup>(4)</sup>
Rated AC power (Pacr @cosφ=1)	20000 W	30000 W	33000 W
Maximum AC output power (Pacmax @cosφ=1)	22000 W up to 30°C	33000 W up to 30°C	36300 W up to 30°C
Maximum apparent power (Smax)	22000 VA up to 30°C	33000 VA up to 30°C	36300 VA up to 30°C
Maximum reactive power (Smax)	20000 VAR	30000 VAR	33000 VAR
Nominal power factor and adjustable range	> 0.995; 0...1 inductive / capacitive		
Rated AC grid voltage (Vac,r)	380V, 400V <sup>(5)</sup>		
Maximum AC output current (Iac,max)	33,4 A	50,1 A	55,1 A
Contributory fault current	Iac,max x 1,15	Iac,max x 1,15	Iac,max x 1,15
Rated output frequency (fr)	50 Hz / 60 Hz		
Output frequency range (fmin...fmax)	47...53 Hz / 57...63 Hz <sup>(2)</sup>		
Max DC Current Injection (% of In)	< 0.5%In		
Maximum AC cable	35 mm² copper/aluminum		
AC connection type	Pluggable Terminal Block		
<b>Output protection</b>			
Anti-islanding Protection	According to local standard		
Maximum external AC overcurrent protection	63 A	80 A	80 A
Output overvoltage protection	SPD Type 2		
<b>Operating performance</b>			
Maximum Efficiency (ηmax)	98.4%	98.4%	98.4%
Weighted Efficiency (EURO)	98.2%	98.2%	98.2%
<b>Environmental</b>			
Operating ambient temperature range	-25...+60°C (-13...140 °F) with derating above 45 °C (113 °F)		
Storage temperature	-40°C...+85°C / -40°F...185°F		
Relative Humidity	4...100 % with condensation		
Sound pressure level, typical	75dB(A) @ 1m		
Maximum operating altitude without derating	4000 m (13123 ft)	4000 m (13123 ft)	4000 m (13123 ft) with output power [Pout ] derating above 3000m (9842 ft) <sup>(6)</sup>
Environmental pollution degree classification for external environments	3		
Environmental class	Outdoor		
<b>Physical</b>			
Inverter typology	Grid connected, Double stage, Transformerless		
Environmental Protection Rating	IP 65		
Cooling System	Forced air		
Dimension (H x W x D)	H = 675 mm / 26.57" (799,2mm / 31.46" with connection boxes); W = 591,8 mm / 23,3"; D = 227,5 mm / 8,95"		
Weight	50 Kg / 110lb		
Overvoltage rating as per IEC 62109-1	II (DC input) III (AC output)		
<b>Safety</b>			
Safety class	I		
Insulation Level	Transformerless		
Marking	CE <sup>(5)</sup>		

1. The AC voltage range may vary depending on specific country grid standards.
2. The Frequency range may vary depending on specific country grid standards.
3. Please refer to the document "String inverters – Product manual appendix" available at [www.abb.com/solarinverters](http://www.abb.com/solarinverters) for information on the quick-fit connector brand and model used in the inverter.
4. Available only with a dedicated version called "SI", with 33kW of power.

5. Hereby, Fimer S.p.A. declares that the radio equipments (radio module combined with the inverter), to which this user manual refers, are in compliance with the Directive 2014/53/EU. The full text of the EU Declaration of Conformity is available at the following internet address: [www.fimer.com](http://www.fimer.com)
6. @ 4000m (45° C ambient temperature), the output power (Pout) is reduced by 10%.
7. 30A (each MPPT): for Australia and New Zealand only.

Features not specifically mentioned in this data sheet are not included in the product.



## FIMER\_PVS-20\_30\_33-TL\_Quick Installation Guide\_EN\_RevA

17-12-2020

For more information please contact your local FIMER representative or visit:

[fimer.com](http://fimer.com)

We reserve the right to make technical changes or modify the contents of this document without prior notice. With regard to purchase orders, the agreed particulars shall prevail. FIMER does not accept any responsibility whatsoever for potential errors or possible lack of information in this document.

We reserve all rights in this document and in the subject matter and illustrations contained therein. Any reproduction, disclosure to third parties or utilization of its contents – in whole or in parts – is forbidden without prior written consent of FIMER. Copyright© 2020 FIMER. All rights reserved.