

# Grid Support Function Rule 14h Settings Review Document for PVS-60-TL-US



## ***General liability warnings concerning inverter use***

Please refer to the Product Manual for complete installation instructions and product use.



ABB accepts no liability for failure to comply with the instructions for correct installation and will not be held responsible for systems upstream or downstream the equipment it has supplied. It is absolutely forbidden to modify the equipment. Any modification, manipulation, or alteration not expressly agreed with the manufacturer, concerning either hardware or software, shall result in the immediate cancellation of the warranty.

The Customer is fully liable for any modifications made to the system.

Given the countless array of system configurations and installation environments possible, it is essential to check the following: sufficient space suitable for housing the equipment; airborne noise produced depending on the environment; potential flammability hazards.

ABB will NOT be held liable for defects or malfunctions arising from: improper use of the equipment; deterioration resulting from transportation or particular environmental conditions; performing maintenance incorrectly or not at all; tampering or unsafe repairs; use or installation by unqualified personnel.

ABB will NOT be held responsible for the disposal of: displays, cables, batteries, accumulators etc. The Customer shall therefore arrange for the disposal of substances potentially harmful for the environment in accordance with the legislation in force within the country of installation.

## ***Field of use, general conditions***

ABB shall not be liable for any damages whatsoever that may result from incorrect or careless operations.



You may not use the equipment for a use that does not conform to that provided for in the field of use. The equipment **MUST NOT** be used by inexperienced staff, or even experienced staff if carrying out operations on the equipment that fail to comply with the indications in this manual and enclosed documentation.

## **Intended or allowed use**

This equipment is a multi-string inverter designed for transforming a continuous electrical current (DC) supplied by a photovoltaic generator (PV) in an alternating electrical current (AC) suitable for feeding into the public distribution network

# Configuration through Web Server

**REQUIRED TOOL:** Device capable to connect to internet for example laptop or smart phone, LAN/WiFi name and password, IP configuration of the inverter, admin account password and admin-plus token (service password).

Before to proceed with the Web Server configuration you need to receive the token to enable the admin-plus account, contact the ABB service with the Serial Number and week/year of production of each inverter to be configured.

Serial Number and week/year of production can be retrieved from the inverter label or from web server.

## PROCEDURE:

Connect the networking device to the same WiFi or LAN of the Inverter then open a browser and insert the inverter IP address on the browser address bar then login to the inverter with the admin account.

Select *Settings* and then *line*, the available settings through web server are shown on figure 1.




Fig. 1: Web Server – Settings Menu

### SA8 ( Anti Islanding Protection)

No configuration possible.

### SA9 (L/HVRT)

Enter on the sub menu AC Settings à *Grid Protections – VRT/FRT*

For each Variable OV2, OV1, UV1, UV2, UV3, the following applies:

*Vgrid Voltage – En / Dis:* to disable and enable the specific protection

*Vgrid Voltage - Value:* set the voltage threshold of the specific variable

*Vgrid Trip Time:* set the trip time threshold of the specific variable

When the “Momentary Cess. General En / Dis” parameter is set to “Enabled”, the activation and trigger points of the Momentary Cessation function associated to voltage transients can be adjusted within this section as follows:

*L/HVRT Momentary Cess. En / Dis: to disable and enable the momentary cessation function associated to LVRT and HVRT transients.*

*HVRT Momentary Cess. Threshold: set the voltage threshold that triggers the momentary cessation during grid overvoltage transients*

*LVRT Momentary Cess. Threshold: set the voltage threshold that triggers the momentary cessation during grid undervoltage transients*



**NOTE: In case voltage protection limits or trip times are modified, please obey the following rules:**

$OV2 \geq OV1$ ; Trip time\_OV1  $\geq$  Trip time\_OV2

$UV1 \geq UV2 \geq UV3$ ; Trip time\_UV1  $\geq$  Trip time\_UV2  $\geq$  Trip time\_UV3

### **SA10 (L/HFRT)**

Enter on the sub menu AC Settings à *Grid Protections – VRT/FRT*

For each Variable OF2, OF1, UF1, UF2 the following applies:

*Grid Frequency – En / Dis: to disable and enable the specific protection*

*Grid Frequency: set the frequency threshold of the specific protection*

*Grid Frequency Trip Time: set the trip time threshold of the specific protection*

When the “Momentary Cess. General En / Dis” parameter is set to “Enabled”, the activation and trigger points of the Momentary Cessation function associated to frequency transients can be adjusted within this section as follows:

*L/HFRT Momentary Cess. En / Dis: to disable and enable the momentary cessation function associated to LFRT and HFRT transients.*

*HFRT Momentary Cessation: set the frequency threshold that triggers the momentary cessation during grid overfrequency transients*

*LFRT Momentary Cessation: set the frequency threshold that triggers the momentary cessation during grid underfrequency transients*



**NOTE: In case frequency protection limits or trip times are modified, please obey the following rules:**

$OF2 \geq OF1$ ; Trip time\_OF1  $\geq$  Trip time\_OF2

$UF1 \geq UF2$ ; Trip time\_UF1  $\geq$  Trip time\_UF2

Refer to the **SA9 Low and High Voltage Ride Through** and **SA10 Low and High Frequency Ride Through** chapters for details about the description of the parameters.

Inverter Parameters <

Search Q

- AC Output Rating >
- AC Settings >**
- Active Power Control >
- Additional Functions >
- DC Settings >
- Digital Inputs >
- Frequency Control: P(f) >
- Ramp Control >
- Reactive Power Control >

Grid Protections - VRT/FF <

|                                  |   |
|----------------------------------|---|
| HFRT Momentary Cessation         | 67 Hz                                       |
| HVRT Momentary Cess. Threshold   | 332.4 V                                     |
| K Factor for LVRT Grid Support   | 0   |
| LFRT Momentary Cessation         | 50 Hz                                       |
| L/HFRT Momentary Cess. En / Dis  | ENABLED <input checked="" type="checkbox"/> |
| L/HVRT Momentary Cess. En / Dis  | ENABLED <input checked="" type="checkbox"/> |
| LVRT Momentary Cess. Threshold   | 133 V                                       |
| Momentary Cess. General En / Dis | ENABLED <input checked="" type="checkbox"/> |
| OF1 Grid Frequency               | 63 Hz                                       |
| OF2 Grid Frequency               | 64 Hz                                       |
| OF1 Grid Frequency - En / Dis    | ENABLED <input checked="" type="checkbox"/> |
| OF2 Grid Frequency - En / Dis    | ENABLED <input checked="" type="checkbox"/> |
| OF1 Grid Frequency Trip Time     | 21 s  |
| OF2 Grid Frequency Trip Time     | 0.16 s                                      |
| OV1 Time Variance - En / Dis     | DISABLED <input type="checkbox"/>           |
| OV2 Time Variance - En / Dis     | DISABLED <input type="checkbox"/>           |
| OV3 Time Variance - En / Dis     | DISABLED <input type="checkbox"/>           |
| OV4 Time Variance - En / Dis     | DISABLED <input type="checkbox"/>           |
| OV5 Time Variance - En / Dis     | DISABLED <input type="checkbox"/>           |
| OV1 Vgrid Trip Time              | 1 s   |
| OV2 Vgrid Trip Time              | 0.16 s                                      |
| OV3 Vgrid Trip Time              | 0.001 s                                     |
| OV4 Vgrid Trip Time              | 0.001 s                                     |
| OV5 Vgrid Trip Time              | 0.001 s                                     |
| OV1 Vgrid Voltage - En / Dis     | ENABLED <input checked="" type="checkbox"/> |
| OV2 Vgrid Voltage - En / Dis     | ENABLED <input checked="" type="checkbox"/> |
| OV3 Vgrid Voltage - En / Dis     | DISABLED <input type="checkbox"/>           |
| OV4 Vgrid Voltage - En / Dis     | DISABLED <input type="checkbox"/>           |
| OV5 Vgrid Voltage - En / Dis     | DISABLED <input type="checkbox"/>           |

Reserved to other standards

Momentary Cessation Voltage & Frequency

Over Frequency (OF) Protections

Over Voltage (OV) Protections Time Variance (Reserved to other standards)

Over Voltage (OV) Protections Trip Time (OV3-OV5, reserved to other standards)

Over Voltage (OV) Protections Enable / Disable (OV3-OV5, reserved to other standards)





Figure 2: L/HVRT Configuration through Web Server

### SA12 (Specified Power Factor)

- (1) Select the **Reactive Power Control**  $\Rightarrow$  **Cos $\phi$  Set** menu from the Inverter Parameters section of the Settings Menu to configure the power factor (PF) according to Utility request.



- (2) **Cos $\phi$  Set** sub-menu will allow you to Enable/Disable the control of the reactive power output of the unit based on a fixed cos $\phi$  and define the value of the cos $\phi$  within the capability limits of the inverter [+ 0.8 to - 0.8 ] for PVS-60-TL-US.




Figure 3: SA12 Specified Power Factor Configuration through Web Server

For details about the above parameters or inverter capability, refer to the description on chapter **SA12 Specified Power Factor Mode**




**NOTE:** Enabling the Power Factor control mode it will automatically disable any other reactive power mode.



**NOTE:** the sign of the power factor is assigned according to the reactive power sign and NOT according to EEI, as described on Annex 1.

**SA13 VV**

- (1) Select the **Reactive Power Control** → **Volt/Var Settings: Q(V)** menu from the Inverter Parameters section of the Settings Menu to configure the Volt-Var mode according to Utility request.



- (2) **Volt/Var Settings: Q(V)** sub-menu will allow you to Enable/Disable the control of reactive power based on the AC terminal voltage by a user(utility)-defined piecewise linear control curve.




Figure 4: SA13 VV Configuration through Web Server



For details about the above parameters or inverter capability, refer to the description on chapter **SA13 VV Volt VAr Mode**



**NOTE:** the sign of the reactive power is assigned with REVERSE values with respect to the EEI reference system specified in Annex 1.

### SA11 SS and SA11 RR

Select the Ramp Control menu to configure the soft start and normal ramp up according to Utility request.

The screenshot shows the 'Ramp Control' configuration page. The left sidebar lists various inverter parameters, with 'Ramp Control' selected. The main content area displays the following settings:

- Normal Ramp-up En / Dis: ENABLED
- Normal Ramp-up Rate: 6000 %Pmax/min
- P max: 60000 W
- SoftStart General En / Dis: ENABLED
- SoftStart Ramp-up Rate: 19.8 %Pmax/min
- SoftStart after AnyFault En/Dis: ENABLED
- SoftStart after GridFault En/Dis: DISABLED

Callout boxes provide further details:

- SA 11 RR (Normal Ramp-up Rate) Enable / Disable**  
Set the Normal Ramp-up Rate  
Note:  $6000\%P_{max}/min = 100\%P_{max}/sec$
- SA 11 SS (Soft start Ramp-up Rate) Enable / Disable**  
Set the Soft Start Ramp-up Rate  
Note:  $19.8\%P_{max}/min = 33\%P_{max}/sec$   
( $19.8 / 60 = 33$ )
- Soft start after Grid Fault (Reserved to other standards)

Figure 5: SA11 Normal Ramp Rate and Soft-Start Configuration through Web Server



**NOTE:** Rule 21 and Rule 14H requires setting the values as %Pn/s. To set properly the value it is necessary to multiply by 60 the SA11 SS and SA11 RR ramp rate values expressed as %Pn/s. For example, a SA11 RR request of 50%Pmax/s should be set on inverter as 3000%Pmax/min.

**SA14 FW**

Select the Frequency Control: P(f) menu to configure the Frequency - Watt according to Utility request.

Figure 6: SA14 FW Configuration through Web Server

**Start and Stop frequency defines also the slope of the Frequency – Watt curve. The slope is defined as:**



$$Slope = P_{max} / (f_{start} - f_{stop}) = 60 \text{ kW} / 2.4 = 41.67 \% [P_n / \text{Hz}]$$

**To deactivate the Frequency - Watt, it is sufficient to disable one between the frequency and the high frequency control flag.**

**To enable the Frequency - Watt, both general and high frequency control flags must be enabled.**

## SA15 VW

Select the *Active Power Control* à *Volt/Watt Settings: P(V)* menu to configure the Volt-Watt function according to Utility request.

The screenshot displays the 'Volt/Watt settings: P(V)' configuration page. The left sidebar shows the navigation menu with 'Active Power Control' selected. The main content area lists the following settings:

- High Voltage Droop Reference Power:** Pref\_OV = Pmax
- P(V) LP Input Filter En/Dis:** ENABLED
- P(V) LP Input Filter Time Constant 3t:** 13.05 s
- P max:** 60000 W
- Point1: V1:** 106 %Vnom
- Point2: V2:** 110 %Vnom
- Point3: V3:** 110 %Vnom
- Point4: V4:** 110 %Vnom
- Point1: W1:** 100 %Pmax
- Point2: W2:** 0 %Pmax
- Point3: W3:** 0 %Pmax
- Point4: W4:** 0 %Pmax
- Regulation Curve Enable/Disable:** DISABLED
- VGrid Nominal:** 277 V

Callout boxes provide the following details:

- Reference Power for Over-voltage droop:** Points to the 'High Voltage Droop Reference Power' setting.
- Volt / Watt P(V) Input Filter:** Points to the 'P(V) LP Input Filter En/Dis' and 'P(V) LP Input Filter Time Constant 3t' settings. Notes: 13.05 time constant 3t = 10s Response time ( 13.05 x 2.3 / 3). This function has effect only with Regulation Curve = ENABLED.
- Volt / Watt P(V) Curve Points:** Points to the V1-V4 and W1-W4 settings. Notes: Point 1:W1...Point 4: W4 = Output power (Watts) of the Point 1....Point 4
- Volt / Watt P(V) Enable / Disable (Unless Enabled required by HECO):** Points to the 'Regulation Curve Enable/Disable' setting.

Figure 7: SA15 VW Configuration through Web Server




Figure 8: Firmware level identification through Web Server .




Figure 9: Selected Country standard identification through Web Server .

# Annex 1: Firmware Compatibility Matrix to Rule 21/14H

This Annex correlate the inverter firmware with the default settings included on this guideline.

If your inverter is not updated to the firmware release within this table then the inverter could have a different default settings with respect to the documents.

In case it is suggested to use the Parameter Adjustment chapter to update the inverter to Rule21 or Rule 14H Utility settings.

| Inverter model | SA8             | SA9 L/HVRT      | SA10 L/HFRT     | SA11 SS         | SA11 RR         | SA12 Spec P f   | SA 13 VV        | SA 14 FW        | SA15 VW         |
|----------------|-----------------|-----------------|-----------------|-----------------|-----------------|-----------------|-----------------|-----------------|-----------------|
| PVS-60-TL-US   | 1915E<br>1.6.14 | 1915E<br>1.6.14 | 1915E<br>1.6.14 | 1915E<br>1.6.14 | 1915E<br>1.6.14 | 1915E<br>1.6.14 | 1915E<br>1.6.14 | 1915E<br>1.6.14 | 1915E<br>1.6.14 |

Table A2: Rule 21 Firmware Compatibility Matrix (minimum firmware level)

| Inverter model | SA8             | SA9 L/HVRT      | SA10 L/HFRT     | SA11 SS         | SA11 RR         | SA12 Spec P f   | SA13 VV         | SA 14 FW        | SA15 VW         |
|----------------|-----------------|-----------------|-----------------|-----------------|-----------------|-----------------|-----------------|-----------------|-----------------|
| PVS-60-TL-US   | 1915E<br>1.6.14 | 1915E<br>1.6.14 | 1915E<br>1.6.14 | 1915E<br>1.6.14 | 1915E<br>1.6.14 | 1915E<br>1.6.14 | 1915E<br>1.6.14 | 1915E<br>1.6.14 | 1915E<br>1.6.14 |

Table A3: Rule 14H Firmware Compatibility Matrix (minimum firmware level)

Tables A2 and A3 define, for each grid support function, the minimum FW release that satisfy the Rule 21/14H default settings described on this application guideline.

Inverter with older firmware could not be aligned, in case the chapter *Parameter Adjustment* describes the procedure to update the inverter settings.

Table A4 defines the starting firmware release of inverters that includes all the Rule 21 function and that can be configured to satisfy the requirements of Rule 21/14H.

| Inverter model | SA8             | SA9 L/HVRT      | SA10 L/HFRT     | SA11 SS         | SA11 RR         | SA12 Spec P f   | SA 13 VV        | SA 14 FW        | SA15 VW         |
|----------------|-----------------|-----------------|-----------------|-----------------|-----------------|-----------------|-----------------|-----------------|-----------------|
| PVS-60-TL-US   | 1915E<br>1.6.14 | 1915E<br>1.6.14 | 1915E<br>1.6.14 | 1915E<br>1.6.14 | 1915E<br>1.6.14 | 1915E<br>1.6.14 | 1915E<br>1.6.14 | 1915E<br>1.6.14 | 1915E<br>1.6.14 |

Table A4: Inverter FW compatible with Rule 21/14H (minimum firmware level)

Firmware XXYYK is encoded as follows:



XX: represents the latest two digit for year of release, for example 18 means 2018

YY: represents the week of release within the year, for example 1803 means 3<sup>rd</sup> week of 2018

K: represents the day of release within the week, for example 1803G means 7<sup>th</sup> day (Sunday) of the 3<sup>rd</sup> day of 2018 and corresponds to 21 January 2018. A firmware is greater than another one if it is released on a later date.

## Document revisions

| Revision | Date                | Change Log   |
|----------|---------------------|--|
| Rev 0.0  | October 18th / 2019 | Specific revision for HECO (PVS-60-TL-US; FW > 1915E - 1.6.14) |

Contact us

[www.abb.com/solarinverters](http://www.abb.com/solarinverters)

